




LOCATION 1:
NEW 24" TRANSMISSION MAIN AND
PRESSURE SUSTAINING VALVE

LOCATION 2:
NEW 8" ISOLATION VALVE

LOCATION 3:
NEW PRESSURE
INDICATING TRANSMITTER

LOCATION 4:
NEW 8" DISTRIBUTION MAIN
AND 16" CHECK VALVE